

CRAFTSMANSHIP in every detail





Blanc Old County Ledge

6-11	Commercial and Residential Applications	44-47	Southern Limestone
12-19	Weatherledge	48-49	Midwest Dimensional
20-25	Old County Ledge	50-51	Salvaged Wood Stone
26-31	Pro Stack	52-53	Fieldstone
32-33	Thin Veneer Brick	54-61	Accessory Guide
34-37	Ledgestone	62	Installation Guide
38-41	Quarry Cut	63	Warranty
42-43	Dressed Ashlar		



Table of Contents





VS Natural Quarried Stone Veneer

- Not weight bearing, no need for a footer or additional reinforcement and expansion joints
- Competitively priced to be well within budget constraints
- Much larger variety of colors and shapes

Bordeaux Creek OLD COUNTY LEDGE





Featured Commercial Applications




Cumberland Fog Pro Stack










Portland Smoke Old County Ledge



Featured Residential Applications





Sequoia Weatherledge





Portland Dusk Old County Ledge



Featured Residential Applications



Moonlit Forest Old County Ledge / Quarry Cut Mix



Jackson Creek Weatherledge






Desert Hollow Weatherledge




- your next venture stand out.
- Eye-catchingly honed, its style is not as rugged or complex. It is to its allure.



• The Weatherledge series is an attractive interweaving of stone that will make

characterized by smoother edges and rectangular pieces that draw you in





• Weatherledge ranges from $1\frac{1}{2}$ inches to 6 inches tall, and 4 inches to $23\frac{1}{2}$ inches long.








Old County Ledge

PORTLAND SMOKE

- stone of choice for those seeking an orderly look.
- This series is a well-organized combination of varied sizes and texture, but with an undeviating line.




• With smooth faces and a modern, angular edge, Old County Ledge is the



7 inches tall, by 4 inches to $23\frac{1}{2}$ inches long.










IMPERIAL

- straight-edged.
- look you've been seeking.



• With a modern look that contains clean and contemporary lines, our ProStack brings you the most current style. The panels are uncluttered, long, and

• Simple yet dynamic, this choice of stone gives you the orderly, unfettered







hin Veneer Brick

FARMHOUSE

- For a rustic flair, our brick is perfect on your next project!
- Thin Veneer Brick is $2\frac{1}{2}$ inches wide by 8 inches long by 1 inch deep.



• Thin Veneer Brick is a throwback to when brick was hand-made and unique.



we mold.



• The Ledgestone series lends abundant character to any project. Rustic with varying depths, the texture is an appealing mix that pleases the eye. Jagged and tapered pieces abound, grasping the essence of the natural ledgestone





Buck Country QUARRY CUT

Moonlit Forest QUARRY CUT

and the second second


Charcoal QUARRY CUT

22

- arranged look.
- apart.

• With a stylish and edgy feel, Quarry Cut fits the bill when you want a well-

• Chic and cultivated with its stack ledge and smaller thin pieces, it brings you uniform lines and diverse color. Perfect for a distinct look to set your design







BRAEMAR

- Dressed Ashlar ranges from 3 inches to 10 inches tall, and 6 inches to 15 inches long.



Dressed Ashlar's straight lines and squared edges will give your next project a strong consistency that exudes culture and refinement.




BRAEMAR

• Southern Limestone's traditional look gives projects a bold and strong



appearance. They are a more natural cut, making it the perfect addition.



thern Limestone is approximately 2½ inches to 16 inches tall, by 5 inches and up to 23½ inches long.




Midwest Dimensional

WHITE ONYX

• Midwest Dimensional offers a natural yet classy appearance to any structure. The contrasting stone sizes give it a grande appearance. Each piece has a soft tone with only a slight variation in color and gentle edges.


• The Midwest series, with dark cool-toned roofing and frames to make a statement, or with softer, warm-toned features for a classic and smooth look.





NATURAL

- project the finish that it deserves.
- 3- 8.5"x 32", 3- 7"x 32", 1- 8.5"x 20", 1- 8.5"x12", 1- 7"x 20", 1- 7"x 12"



• Minutely detailed, Salvaged Wood Stone brings a fresh line to your space with its weathered details. The striking reclaimed texture of this stone will give your

• Salvaged Wood Stone has the following included in the box: (Not sold by the individual piece)




PORTLAND SMOKE

- invitation to come home and unwind.
- Fieldstone ranges from 4 inches to approximately 22 inches.



• Choosing a homey look with stone brings an exciting blend of variables to choose from. Our Fieldstone clarifies this style and brings it to the forefront. With a varied and irregular woodsy union of shapes, this series is a warm

Accessory Sizing Guide



Imperial Pro Stack with white Rowlocks and Water Table Sills

54





Accessory Color Reference Guide







Accessory Color Reference Guide


	PRO STACK	PRO STACK	MIDWEST DIMENSIONAL	OLD COUNTY LEDGE	DRESSED ASHLAR	WEATHERLEDGE
SIESTA						VENICE
MOONLIT FOREST			QUARRY CUT		BURNT RUSSET	
NATURAL					SEQUOIA	
PORTLAND DUSK					PORTLAND SMOKE / SMOKEY	
BLACK ONYX					JACKSON CREEK	
IMPERIAL		WHITE ONYX	MIDWEST DIMENSIONAL		IMPERIAL	
All	colors listed here are	for suggestion only a	nd are solely at the disc	cretion of the user.	For color, please r	eference stone samples







Accessory Color Reference Guide



60




SUGGESTED COLORS Gray White Charcoal Tan MIDWEST DIMENSIONAL SUGGESTED COLORS QUARRY CUT BBI Tan Brown Tan Z Gray White Charcoal **OLD COUNTY LEDGE** Gray White For color, please reference stone samples or current installations for color representation.




Warranty Information

1. INSTALLATION OVER WOOD FRAMING



2. INSTALLATION OVER CONCRETE **MASONRY UNITS**



APPLYING THE METAL LATH

Apply a moisture barrier of housewrap and 30 pound felt. Overlap horizontal joints 5 inches and vertical joints 8 inches. All corners must be wrapped a minimum of 16 inches. must be overlapped in the same manner as the felt. Fasten with wide crown staples at least 1 inch in length. Make to wet down the back of the stone or the scratch coat. sure all chimneys and windows are properly flashed.

APPLYING THE SCRATCH COAT

Apply a scratch coat using Type M or Type N mortar, approximately $\frac{1}{4}$ inch to $\frac{1}{2}$ inch thick. Make sure the mortar is not too wet or too dry.

APPLYING THE STONE

Install corners first. Spread mortar evenly on the back of the stone, approximately $\frac{1}{2}$ inch thick. When applying the stone to the wall, move the stone back and forth a little bit Then apply 2.5 pound metal lath or equivalent. Metal lath in a circular motion. Make sure your mortar is not too dry or too wet for proper bonding. In hot weather you may need

GROUTING INSTRUCTIONS

Use a grout bag to grout the joints, making sure you do not get cement on the face of the stone. Let the grout ioint set up until it is slightly dry, then strike the joint with a jointer or other similar implement. Make sure it isn't too wet or too dry. If the mortar wets or stains a brush it is too wet. Brush out the joints with a soft brush.



Scan for the MVMA Installation Guide



 50 year Limited Warranty from the date of purchase, when installed to Manufacturer's instructions and according to local building codes. Warranty does not cover damaged product resulting from building settlement, wall movement, improper installation, or discoloration due to airborne contaminants.

• The Contractor and Architect are responsible for proper installation. Prestige Stone Products, llc is not responsible for the structural wall surface it is applied to. Make sure to follow all of your local building codes. Building codes will vary from state to state, county to county.

• Warranty is subject to all other terms of the written warranty, a copy of which can be obtained from your dealer or by visiting:

www.prestigestoneproducts.com

SPECIAL CONSIDERATIONS FOR PRO STACK / TIGHT STACK INSTALLATIONS

Compared to other masonry installations where a grout joint is visible and surrounds each piece, tight fitting modular installations don't have a true grout joint reinforcement to lock in stone improving adherence. It is recommended to use a compliant Polymer Modified Mortar or bonding agent and proper installation techniques. A full, complete mortar setting bed is mandatory and will provide an effective seal behind and around the stone. Joint installations using regular type mortars don't experience such adherence deficiencies because the grout serves as an additional bonding area around the edges of each veneer piece and tends to lock each piece in place. Grout seals the area surrounding each veneer piece from water infiltration to the back of the veneer. If water collects in the voids behind the veneer and freezes, expansive forces can cause the veneer to disengage.

SUMMARY

Choose the proper mortar. Standard type S or N Mortar is suitable for jointed grouted veneer. For a Pro Stack type application use a polymer Modified Mortar complying with ANSI A118.4 or ANSI A118.15 Or equivalent, or a liquid bonding agent.

Ensure that wall bonding surfaces and back of the veneer are free of dust, laitance, loose concrete particles, and any film that could impede a bond.

manufacturer's recommendations regarding "wetting" when using polymer modified mortar.

Completely butter each veneer piece, ($\frac{1}{2}$ ") and work firmly into place.

Ensure complete mortar setting bed coverage and full perimeter. "Squeeze out"

back buttered onto the veneer.

Do not dislodge previously installed veneer. Mortar bond may be compromised.

SET THE VENEER SECURELY

This cannot be emphasized enough- the veneer must be pressed firmly into the mortar setting bed, and onto the scratch coat and worked delicately back and forth with a slight rotating action. You must achieve mortar squeeze out in a volume that results in full mortar setting bed covering the scratch coat and the back of the veneer completely. Over "buttering" will also effect bond efficacy. Once the veneer has set it should not be dislodged or the bond may be compromised. Care should be taken to avoid inadvertent movement after the initial set, especially with tight fit installations where veneer pieces are intentionally touching each other.



- When applying Type S or N mortar, wet the scratch coat and back of each veneer piece. Check the mortar
- Mix mortar with proper amount of sand and water to form proper consistency for maximum adherence.
- If necessary, use a mortar application method in which mortar is troweled onto the scratch coat, and also





9290 Winesburg Road Dundee, OH 44624 www.prestigestoneproducts.com 330.439.5318

