



8-FOOT RIGID PAVER EDGING

UPDATE

April 23, 2018

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: techniseal.com
U.S.A. and Canada: dial 1 800 465-7325
Others: dial (514) 523-8324 (Canada)

APPLICATIONS

- Perfect to define driveways, patios, alleys and walkways.

PROPERTIES

- Easy snap connection
- Can easily be cut on the ground
- Convenient and easy to use
- Heavy duty Injection molded
- Made from 100% recycled material

DESCRIPTION

The 8-Foot Rigid Paver Edging from Techniseal is the most advanced paver edging on the market. Its installation is quick and effortless as it is the only edging that can be cut directly on the ground, making installation a breeze. Lengths join seamlessly with the integrated connectors. "Lobster Tail" design allows installer to double-spike, eliminating any risk of frost lift. It is also handy for spike off-set, in case of obstruction below grade.

DIRECTIONS

BEFORE YOU BEGIN

Before proceeding with the installation, make sure you have an up-to-date technical data sheet in hand visiting techniseal.com.

Necessary tools:




- Standard hammer
- Hacksaw
- Tin snips

ANCHORING AND INSTALLATION

For patios and walkways: 1 spike every 16 to 20 inches (40 to 50 cm) and at each end.

For driveways and heavy load areas: 1 spike every 8 to 12 inches (20 to 30 cm) and at each end.

1. Determine the amount of edging required by measuring the exterior perimeter of the project.
2. Edgings should be installed after the paver installation.
3. Lay edgings along the perimeter of the pattern with the tabs facing outwards.
4. Start anchoring the edgings using Techniseal nails. To prevent the edging from pulling away from the paver edge, it is suggested to install nails between the rail and the strap.
5. Edging can be easily bent by hand to form any curve. To bend the edging, simply use tin snips to cut the rail at an angle. The rail can be cut on the ground, as you go.
6. Connect edging sections together with the easy snap connectors. Sections can be cut with a simple hacksaw.



SHIPPING

Land and sea

NOT REGULATED

PACKAGING

8' Edging	Product Code	Color	Unit Size	Units per pack	Packs per pallet	Units per pallet
	70971148 (245-950)	Black	8' (243cm)	10 80' (24m)	63	630 5040' (1536m)



Low-Profile Aluminium Edging

UPDATE

November 13, 2020

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: techniseal.com

U.S.A. and Canada: dial 1 800 465-7325

Others: dial (514) 523-8324 (Canada)

APPLICATIONS

- Perfect to define driveways, patios, alleys and walkways
- Works with natural stone, concrete paver, concrete slab, interlocking paver, porcelain tile.

PROPERTIES

- Discreet - A low profile design that conceals the edging for a crisp installation.
- Weather-resistant - Won't deteriorate from exposure to the sun, frost, etc
- Flexible by hand - Easy to bend into any curve or create 90° angles without cutting
- Versatile - Ideal for the installation of pavers, flagstones, bluestones, granite, porcelain pavers and more.
- Each section is 8'4" long and 5/8" tall
- Made of 6063 aluminum alloy with T-5 hardness.
- Works on granular base as well as with EZ Base panels.
- Convenient and easy to use.
- Made from 100% recycled material and recyclable.
- Material will not rust.

DESCRIPTION

This discreet low-profile aluminium landscape edging is highly flexible and can be bent into any curve or used to create 90° without cutting. Very durable, it prevents pavers, natural stones, and porcelain tiles from shifting or moving.

DIRECTIONS

BEFORE YOU BEGIN

Before proceeding with the installation, make sure you have an up-to-date technical data sheet in hand visiting techniseal.com.

NECESSARY TOOLS

- Standard hammer or small mass
- Hacksaw
- Tin snips

ANCHORING AND INSTALLATION

For patios and walkways : 1 spike every 18 inches (45 cm) and at each end.

For driveways : 1 spike every 12 inches (30 cm) and at each end.

1. Determine the amount of edging required by measuring the exterior perimeter of the project.
2. Edgings should be installed after the paver installation.
3. Lay edgings along the perimeter of the pattern with the tabs facing outwards.
4. Start anchoring the edgings using Techniseal Paving Edging Nails (70971150).
5. Edging can be easily bent by hand to form any curve or to create sharp angles.
6. Sections can be cut with a simple hacksaw or tin snips in order to achieve a clean cut.
7. Position nails at recommended spacing and drive nails into the ground using hammer or small mace.

STORAGE AND SHELF LIFE

- The Low-Profile Aluminum Edgings are made of 100% recycled materials and are recyclable.

SAFETY WARNINGS

- Wear appropriate safety gears.
- Be cautious not to strike fingers or hand when hitting paving edging nails with hammer.

SHIPPING

Land and sea:

Not regulated

PACKAGING

PRODUCT CODE	COLOR	SIZE	UNITS PER BOX	BOXES PER PALLET	UNITS PER PALLET
70973071	Aluminium	8'4" / 2.54 m	30	20	600