



NATURAL LOOK (iN)

PAVING PROTECTOR - MATTE FINISH - WATER BASED

UPDATE

January 30, 2019

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: techniseal.com
U.S.A. and Canada: dial 1 800 465-7325
Others: dial (514) 523-8324 (Canada)

APPLICATIONS

- For concrete pavers, clay pavers, wet-cast pavers, poured concrete and natural stone
- Recommended for pool decks, patios, walkways and retaining walls

PROPERTIES

- Preserves the natural look
- Ideal for slip-prone surfaces
- Stain guard - repels contaminants
- Impregnating - non-film forming
- Penetrating - won't make surface more slippery

DESCRIPTION

Made of water-and oil repellent agents, NATURAL LOOK (iN) Protector is specially designed to protect concrete, clay and wet-cast pavers, poured concrete and natural stone. It prevents deterioration due to chemical products such as de-icing salts, while providing resistance to acids and alkalis. Its active agents form an invisible bond that stops the penetration of contaminants, facilitating the maintenance of the surface. Water based, NATURAL LOOK does not release unpleasant fumes and is environmentally friendly.

DIRECTION

APPLICATION TO CONCRETE PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with iN Protector from Techniseal. Wait until the Protector is worn before recoating the surface (minimum 2 years)
- Perform a water absorption test* on multiple areas of the surface to be sealed to confirm that the water-based Protector will easily penetrate the pavers.
- With the appropriate stripper, remove any unknown coating that was previously applied.

*ABSORPTION TEST: Sprinkle a few drops of water on surface. If water is repelled, do not apply this product.

SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner) as directed on product label.

APPLICATION

Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

Necessary Tools:

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap roller and paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 100 sq. ft. Apply in such a way that you can return to each section without walking on fresh protector (2 coats wet-on-wet technique).

Sprayer Application (Best Practice): Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector. Remove excess with the roller. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge in order to prevent overlap marks.

Roller Application: Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector, avoiding accumulation of excess product. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector will not trap efflorescence which will disappear by itself after prolonged exposure to weathering.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- An over-accumulation of product could make dust stick onto the surface.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO WET-CAST PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with iN or WC Protector from Techniseal.
- Wait until the Protector is worn before recoating the surface (minimum 2 years)
- Perform a water absorption test* on multiple areas of the surface to be sealed to confirm that the water-based Protector will easily penetrate in the pavers.
- With the appropriate stripper, remove any unknown coating that was previously applied.

*ABSORPTION TEST: Sprinkle a few drops of water on surface. If water is repelled, do not apply this product.

SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the wet-cast paver manufacturer. Once installed, a layer of efflorescence-like dust can form on the surface of some wet-cast pavers after a few days. It is critical that this layer be removed prior to applying the Protector.

APPLICATION

Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

Necessary Tools:

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap roller and paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 100 sq. ft. Apply in such a way that you can return to each section without walking on fresh protector (2 coats wet-on-wet technique).

Sprayer Application (Best Practice): Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector. Remove excess with the roller. **If the wet-cast paver is very porous, immediately upon completion of a section,** apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge in order to prevent overlap marks.

Roller Application: Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector, avoiding accumulation of excess product. **If the wet-cast paver is very porous, immediately upon completion of a section,** apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector will not trap efflorescence which will disappear by itself after prolonged exposure to weathering.
- Do not attempt sprayer application on windy days
- Do not apply this product over a blotchy or hazed surface
- Inadequate surface cleaning can result in uneven finish
- An over-accumulation of product could make dust stick onto the surface.
- Extreme climate or heavy traffic can limit product longevity.

APPLICATION TO NATURAL STONE

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped concrete.
- Consult with the stone manufacturer to see if your stones can be sealed. This penetrating Protector can be used with **porous** natural stones only.
- Do not apply to polished natural stone.
- Apply only to a bare material or to materials previously sealed with this product.
- Wait until the Protector is worn before recoating the surface (minimum 2 years).
- Perform a water absorption test* on multiple areas of the surface to be sealed to confirm that the water based Protector will easily penetrate in the stones.
- With the appropriate stripper, remove any unknown coating that was previously applied.

*ABSORPTION TEST: Sprinkle a few drops of water on surface. If water is repelled, do not apply this product.

SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the stone manufacturer.

APPLICATION

Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

Necessary Tools:

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap roller and paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft. Apply in such a way that you can return to each section without walking on fresh protector (2 coats wet-on-wet technique).

Sprayer Application (Best Practice): Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector. With a dry roller or a lint-free dry rag, remove the excess from the surface before it dries (this step is critical). **If the natural stone is very porous, immediately upon completion of a section**, apply a second coat following the same method. Maintain a wet edge to prevent overlap marks.

Roller Application: Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector. With a dry roller or a lint-free dry rag, remove the excess from the surface before it dries (this step is critical). **If the natural stone is very porous, immediately upon completion of a section**, apply a second coat following the same method. Maintain a wet edge to prevent overlap marks.

CAUTION

- All natural stones are unique and will age differently. This Protector will not prevent the aging phenomenon from occurring.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven wet look.
- An over-accumulation of product could make dust stick onto the surface.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO CLAY PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with iN Protector from Techniseal.
- Wait until the Protector is worn before recoating the surface (minimum 2 years).
- Perform a water absorption test* on multiple areas of the surface to be sealed to confirm that the water-based Protector will easily penetrate the pavers.
- With the appropriate stripper, remove any unknown coating that was previously applied.

*ABSORPTION TEST: Sprinkle a few drops of water on surface. If water is repelled, do not apply this product.

SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the clay paver manufacturer.
4. Ensure the pavers are completely dry before applying the Protector. This step can take a few days with clay pavers.

APPLICATION

Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

Necessary Tools:

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap roller and paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 100 sq. ft. Apply in such a way that you can return to each section without walking on fresh protector (2 coats wet-on-wet technique).

Sprayer Application (Best Practice): Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector. Remove excess with the roller. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge in order to prevent overlap marks.

Roller Application: Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector, avoiding accumulation of excess product. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

CAUTION

- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- An over-accumulation of product could make dust stick onto the surface.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO POURED CONCRETE**BEFORE YOU BEGIN**

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped concrete.
- Do not apply to polished materials.
- Wait at least 28 days before applying this Protector to freshly poured concrete.
- Wait until the Protector is worn before recoating the surface (minimum 2 years).
- Perform a water absorption test* on multiple areas of the surface to be sealed to confirm that the water-based Protector will easily penetrate the surface.
- With the appropriate stripper, remove any unknown coating that was previously applied.

*ABSORPTION TEST: Sprinkle a few drops of water on surface. If water is repelled, do not apply this product.

SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with the appropriate cleaner.

APPLICATION**Application Conditions:**

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

Necessary Tools:

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap roller and paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 100 sq. ft. Apply in such a way that you can return to each section without walking on fresh protector (2 coats wet-on-wet technique).

Sprayer Application (Best Practice): Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector avoiding accumulation of excess product. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge in order to prevent overlap marks.

Roller Application: Work in sections of no more than 100 sq. ft. **Saturate** the surface with a first coat of Protector, avoiding accumulation of excess product. Immediately upon completion of a section, apply a second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

CAUTION

- Any new concrete has the potential to produce efflorescence (whitish salts) on its surface. • This Protector will not trap efflorescence which will disappear by itself after prolonged exposure to weathering. • Do not attempt sprayer application on windy days. • Do not apply this product over a blotchy or hazed surface. • Inadequate surface cleaning can result in uneven finish. • An over-accumulation of product could make dust stick onto the surface. • Extreme climate or heavy traffic could limit product longevity.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 to 72 h. Block access during that period.

COVERAGE

As a concrete, clay and wet-cast paver sealer: single-coat application 1 gal. covers up to 120 sq. ft.; 5 gal. cover up to 600 sq.ft.

As a natural stone sealer: single-coat application 1 gal. covers up to 120 sq. ft.; 5 gal. cover up to 600 sq.ft.

As a poured concrete sealer: 1 gal. covers up to 200 sq. ft.; 5 gal. cover up to 1000 sq.ft.

Coverage will depend on joint width and type as well as surface porosity.

STORAGE

Keep from freezing. Store in a cool, dry place.

CLEANING & DISPOSAL

Wash tools and hands with warm soapy water. Consult your retailer or community agency for disposal of empty containers or unused product.

PACKAGING

Product Code	Size	Units per box	Units per pallet
60305100	1 gal.	2	180
60304120	5 gal.	-	48
60101971	55 gal. (special order)	-	4

SHIPPING

Land and Sea

NOT REGULATED

HANDLING AND SAFETY

For information and advice regarding transportation, handling, storage, first aid and disposal of chemicals products, users should refer to the actual Safety Data Sheet containing physical, ecological, toxicological and other safety-related data.

KEEP OUT OF THE REACH OF CHILDREN
EMERGENCY PHONE: CANUTEC (613) 996-6666

LIMITED WARRANTY

Having no control over the use of the products, Techniseal® does not guarantee finished work. Replacement of any defective product shall be the buyer's sole remedy under this warranty. A proof of purchase will be required for any claim. Before using this product, user shall determine the suitability of the product for its intended use, and user alone assumes all risks and liability whatsoever in connection therewith. User shall test product in a small inconspicuous area (approx. 4 sq. ft.) under projected conditions of use. In the event that no test was carried out, the warranty will only apply to 4 sq. ft. This limited warranty excludes any liability for any consequential, incidental, indirect or special damages. Except for the limited warranty described above, manufacturer specifically disclaims and excludes any other express warranty, any implied warranty of merchantability of goods, and implied warranty of fitness of goods for any particular purpose.



Color Boost (CB+) Paver Protector Penetrating Sealer Matte Finish - Water-Based

UPDATE

August 3, 2020

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: techniseal.com

U.S.A. and Canada: dial 1 800 465-7325

Others: dial (514) 523-8324 (Canada)

APPLICATIONS

- Recommended for pool decks, patios, walkways and retaining walls

PROPERTIES

- Enhance the color of pavers
- Ideal for slip-prone surfaces
- Stain guard – repels contaminants
- Impregnating – non-film forming
- Penetrating – won't make surface more slippery
- Water-based

DESCRIPTION

COLOR BOOST (CB+) Protector is specially designed to protect and enhance the color of porous concrete pavers and natural stone. It prevents deterioration due to chemical products such as de-icing salts, while providing resistance to acids and alkalis. Its active agents form an invisible bond that stops the penetration of contaminants, facilitating the maintenance of pavers and natural stone. Water-based, COLOR BOOST (CB+) Protector does not release unpleasant fumes and is environmentally friendly.

Not to be sold in SCAQMD and in the state of Utah.

DIRECTIONS

APPLICATION TO CONCRETE PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty). To determine if one or two coats will be required, apply a first coat over the testing area; wipe off excess product and apply a second coat over half the testing surface. Allow the surface to dry completely before making the final selection.

• **Do not apply** to wet-cast or clay pavers, stamped or poured concrete. • Do not apply to polished material. • Apply only to bare materials* or to materials previously sealed with this product. • Wait until the Protector is worn before recoating the surface (minimum 2 years). • With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (CONCRETE PAVERS)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label.

APPLICATION CONDITIONS

- Surface must be **porous**, clean, dry and warm to the touch.
- Temperature must be between 55 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice).
- 3/8" polyester nap roller and paint tray.

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.. If a second coat is needed, apply in such a way that you can return to each section without walking on fresh Protector (2 coats wet-on-wet technique)

Sprayer Application (Best Practice): Saturate the surface with a coat of Protector. With a roller, remove the excess from the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

Roller Application: Saturate the surface with a coat of Protector, avoiding an accumulation of excess product. With a dry roller, remove excess on the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

***Second coat: Apply a second coat only if the surface is very porous.** The application of a second coat over pavers that are not sufficiently porous will make the surface slippery and could create a glossy finish.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 h to 72 h. Block access during that period.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector will not trap efflorescence, which will disappear by itself after prolonged exposure to weathering.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Surface might be slightly slippery for a few days following the application.
- An over-accumulation of product could lead to an uneven gloss on the surface.
- Wait 30 days after the installation of polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO NATURAL STONE

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty). To determine if one or two coats will be required, apply a first coat over the testing area; wipe off excess product and apply a second coat over half the testing surface. Allow the surface to dry completely before making the final selection.

- **Do not apply** to wet-cast or clay pavers, stamped or poured concrete.
- Consult with the stone manufacturer to see if the stones can be sealed.
- This penetrating Protector can be used with porous natural stones only.
- Do not apply to polished natural stone.
- Apply only to bare materials* or to materials previously sealed with this product.
- Wait until the Protector is worn before recoating the surface (minimum 2 years).
- With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (NATURAL STONE)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate stain removers.
3. Prepare the entire surface following recommendations from the stone manufacturer.

APPLICATION CONDITIONS

- Surface must be **porous**, clean, dry and warm to the touch.
- Temperature must be between 55 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice).
- 3/8" polyester nap roller and paint tray.

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.. If a second coat is needed, apply in such a way that you can return to each section without walking on fresh Protector (2 coats wet-on-wet technique)

Sprayer Application (Best Practice): Saturate the surface with a coat of Protector. With a roller or a lint-free dry rag, remove the excess from the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

Roller Application: Saturate the surface with a coat of Protector, avoiding an accumulation of excess product. With a dry roller or a lint-free dry rag, remove excess on the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

***Second coat: Apply a second coat only if the surface is very porous.** The application of a second coat over natural stones that are not sufficiently porous will make the surface slippery and could create a glossy finish.

CAUTION

- All natural stones are unique and will age differently. This Protector will not prevent the aging phenomenon from occurring.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface preparation can result in uneven finish.
- Surface might be slightly slippery for a few days following the application.
- An over-accumulation of product could lead to an uneven gloss on the surface.
- Wait 30 days after the installation of polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO RETAINING WALLS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty). To determine if one or two coats will be required, apply a first coat over the testing area; wipe off excess product and apply a second coat over half the testing surface. Allow the surface to dry completely before making the final selection.

• **Do not apply** to wet-cast retaining walls. • Do not apply to polished material. • Apply only to bare materials* or to materials previously sealed with this product. • Wait until the Protector is worn before recoating the surface (minimum 2 years). • With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (RETAINING WALLS)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate stain removers.
3. Prepare the entire surface following recommendations from the retaining wall manufacturer.

APPLICATION CONDITIONS

- Surface must be **porous**, clean, dry and warm to the touch.
- Temperature must be between 55 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice).
- 3/8" polyester nap roller and paint tray.

Do not dilute. Shake well or stir product before and during application.

Sprayer Application (Best Practice): Apply **downwards** from the top. **Saturate** the surface with a coat of Protector. With a roller, remove the excess from the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

Roller Application: Apply **downwards** from the top. Work in sections of no more than 50 sq. ft.. **Saturate** the surface with a coat of Protector, avoiding an accumulation of excess product. With a dry roller, remove excess on the surface before it dries (this step is critical). If a second coat* is needed, immediately upon completion of a section, apply the second coat following the same method. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

***Second coat: Apply a second coat only if the surface is very porous.** The application of a second coat over a surface that is not sufficiently porous could create a glossy finish.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector will not trap efflorescence, which will disappear by itself after prolonged exposure to weathering.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface preparation can result in uneven finish.
- An over-accumulation of product could lead to an uneven gloss on the surface.
- Extreme climate or heavy traffic could limit product longevity.

COVERAGE

1 gallon covers up to 150 sq. ft. per coat / 5 gallons cover up to 750 sq. ft. per coat.

A second coat will cover more.

Coverage will depend on joint width and type as well as surface porosity.

STORAGE

Keep from freezing. Store in a cool, dry place.

CLEANING & DISPOSAL

Wash tools and hands with warm soapy water. Consult your retailer or municipality regarding the disposal of empty containers or unused product.

SAFETY WARNINGS

For information and advice regarding transportation, handling, storage, first aid and disposal of chemicals products, users should refer to the actual **Safety Data Sheet** containing physical, ecological, toxicological and other safety-related data.

KEEP OUT OF THE REACH OF CHILDREN

EMERGENCY PHONE: CANUTEC (613) 996-6666

Do not get in eyes. Do not get on skin or clothing.

FIRST AID TREATMENT If swallowed, call a Poison Control Centre or doctor immediately. Do not induce vomiting. If in eyes, rinse with water for 15 minutes. If on skin, rinse well with water.

SHIPPING

Land and sea

NOT REGULATED

PACKAGING

Product	Product code	Size	Units per box	Units per pallet
Color Boost (CB+) Protector	60301612	1 gallon	2	180
	60301611	5 gallons	-	48

LIMITED WARRANTY

Having no control over the use of the products, Techniseal® does not guarantee finished work. Replacement of any defective product shall be the buyer's sole remedy under this warranty. A proof of purchase will be required for any claim. Before using this product, user shall determine the suitability of the product for its intended use, and user alone assumes all risks and liability whatsoever in connection therewith. User shall test product in a small inconspicuous area (approx. 4 sq. ft.) under projected conditions of use. In the event that no test was carried out, the warranty will only apply to 4 sq. ft. This limited warranty excludes any liability for any consequential, incidental, indirect or special damages. Except for the limited warranty described above, manufacturer specifically disclaims and excludes any other express warranty, any implied warranty of merchantability of goods, and implied warranty of fitness of goods for any particular purpose.



Wet Look (WL5) Paver Protector Sealer & Joint Stabilizer Gloss Finish - Solvent-Based



UPDATE

August 6, 2020

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: techniseal.com

U.S.A. and Canada: dial 1 800 465-7325

Others: dial (514) 523-8324 (Canada)

APPLICATIONS

- For concrete & wet-cast pavers, natural stone and aggregates
- Recommended for driveways, parking lots, patios and walkways

PROPERTIES

- Enhance the color of pavers
- Stabilizes sand or aggregate joints
- Stain guard
- Forms a protective film

DESCRIPTION

Made of acrylic and plasticizers, WET LOOK (WL5) Protector is specially designed to protect natural stone, concrete and wet-cast pavers and to stop the movement of aggregates or sand (conventional paver joints) while imparting a wet look gloss to surfaces. It prevents deterioration caused by chemical products such as de-icing salts, while providing resistance to acids and alkalis. Its transparent film stops the penetration of contaminants, facilitating the maintenance of pavers.

Not to be sold in SCAQMD and in the state of Utah.

DIRECTIONS

APPLICATION TO CONCRETE PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

• **Do not apply** to stamped or poured concrete. • Do not apply to polished material. • Apply only to bare material* or to material previously sealed with WL1-2, WL4 or WL5 Protectors from Techniseal. • Wait until the Protector is worn before recoating the surface (2 years minimum). • With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** Sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (CONCRETE PAVERS)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label.

APPLICATION CONDITIONS

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure solvent-resistant (acetone) airless sprayer (< 50 psi) or solvent-resistant (acetone) pump sprayer (best practice)
- Techniseal® Slit-Foam Roller and solvent-resistant paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.

Sprayer Application (Best Practice): Saturate a section with a single coat of Protector. With the roller, remove the excess on the surface before it dries. Repeat for subsequent sections, maintaining a wet edge in order to avoid overlapping marks.

Roller Application: Saturate the surface with a single coat of Protector, avoiding an accumulation of excess product. Maintain a wet edge in order to avoid overlapping marks.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 h to 72 h. Block access during that period.

CAUTION

• Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film-forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1 800 465-7325 for more information. • Do not attempt sprayer application on windy days. • Do not apply this product over a blotchy or hazed surface. • Inadequate surface cleaning can result in uneven finish. • This product will make the surface more slippery when wet. If slipping is a concern, consider Techniseal® Color Boost (CB) Protector or adding Surefoot anti-slip grit from Techniseal® in the Protector before the application. Color Boost (CB) is not a joint stabilizer. • Wait 30 days after the installation of polymeric sand before sealing the pavers. • An over-accumulation of product could lead to surface whitening. • Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO WET-CAST PAVERS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

• **Do not apply** to stamped or poured concrete. • Do not apply to polished material. • Apply only to bare material* or to material previously sealed with WL1-2 or WCS Protectors from Techniseal. • Wait until the Protector is worn before recoating the surface (2 years minimum). • With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** Sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (WET-CAST PAVERS)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate stain removers.
3. Prepare the entire surface following recommendation from the wet-cast paver manufacturer. Once installed, a layer of efflorescence-like dust can form on the surface of some wet-cast pavers after a few days. It is critical that this layer be removed prior to applying the Protector.

APPLICATION CONDITIONS

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure solvent-resistant (acetone) airless sprayer (< 50 psi) or solvent-resistant (acetone) pump sprayer (best practice)
- Techniseal® Slit-Foam Roller and solvent-resistant paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.

Sprayer Application (Best Practice): Saturate a section with a single coat of Protector. With the roller, remove the excess on the surface before it dries. Repeat for subsequent sections, maintaining a wet edge in order to avoid overlapping marks.

Roller Application: Saturate the surface with a single coat of Protector, avoiding an accumulation of excess product. Maintain a wet edge in order to avoid overlapping marks.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 h to 72 h. Block access during that period.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film-forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1 800 465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding Surefoot anti-slip grit from Techniseal® in the Protector before the application
- Wait 30 days after the installation of polymeric sand before sealing the pavers.
- An over-accumulation of product could lead to surface whitening.
- Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO NATURAL STONE

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- **Do not apply** to stamped or poured concrete.
- Consult with the stone manufacturer to see if your stones can be sealed.
- This Protector can be used with porous natural stones only. It is not suitable for granite, marble or dense natural stones.
- Do not apply on polished natural stone.
- Apply only to bare material* or to material previously sealed with WL1-2 or WL5 Protectors from Techniseal.
- Wait until the Protector is worn before recoating the surface (2 years minimum)
- With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** Sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (NATURAL STONE)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate stain removers.
3. Prepare the entire surface following recommendation from the stone manufacturer.

APPLICATION CONDITIONS

- Surface must be **porous**, clean, dry and warm to the touch.
- Temperature must be between 50 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over the entire surface.

NECESSARY TOOLS

- Low-pressure solvent-resistant (acetone) airless sprayer (< 50 psi) or solvent-resistant (acetone) pump sprayer (best practice)
- Techniseal® Slit-Foam Roller and solvent-resistant paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.

Sprayer Application (Best Practice): Saturate a section with a single coat of Protector. With the roller, remove the excess on the surface before it dries. Repeat for subsequent sections, maintaining a wet edge in order to avoid overlapping marks.

Roller Application: Saturate the surface with a single coat of Protector, avoiding an accumulation of excess product. Maintain a wet edge in order to avoid overlapping marks.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 h to 72 h. Block access during that period.

CAUTION

- All natural stones are unique and will age differently. This Protector will not prevent the aging phenomenon from occurring.
- Do not attempt sprayer application on windy days. • Do not apply this product over a blotchy or hazed surface. • Inadequate surface preparation can result in uneven finish. • This product will make the surface more slippery when wet. If slipping is a concern, consider adding Surefoot anti-slip grit from Techniseal® in the Protector before the application. • An over-accumulation of product could lead to an uneven gloss on the surface. • Wait 30 days after the installation of polymeric sand before sealing the pavers. • Extreme climate or heavy traffic could limit product longevity.

APPLICATION TO STABILIZE SAND OR AGGREGATE JOINTS

BEFORE YOU BEGIN

ALWAYS TEST on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- **Do not apply** to stamped or poured concrete. • Do not apply to polished material. • Apply only to bare material* or to material previously sealed with WL1-2, WL5 or JSS Protectors from Techniseal. • Wait until the Protector is worn before recoating the surface (minimum 2 years). • With the appropriate stripper, remove any unknown coating that was previously applied.

***ABSORPTION TEST:** Sprinkle a few drops of water on surface. If water is absorbed, move on to the next point. If water is repelled, do not apply this product.

SURFACE PREPARATION (JOINT STABILIZATION)

1. Protect vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label.

APPLICATION CONDITIONS:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 °F and 85 °F during the application and for the next 24 hours.
- No rain should be forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

NECESSARY TOOLS:

- Low-pressure solvent-resistant (acetone) airless sprayer (< 50 psi) or solvent-resistant (acetone) pump sprayer (mandatory)
- 3/8" polyester nap roller and solvent-resistant paint tray

Do not dilute. Shake well or stir product before and during application. Work in sections of no more than 50 sq. ft.

Sprayer Application: Saturate surface with a single coat of Protector. With the roller, redirect the excess product from the surface into the joints. Avoid displacing the aggregates with the roller. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

TRAFFIC

Pedestrian: 24 h. / Vehicular: 48 h to 72 h. Block access during that period.

CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film-forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1 800 465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- This product will make the surface more slippery when wet. If slipping is a problem, consider adding Surefoot anti-slip grit from Techniseal® in the Protector before the application.
- An overaccumulation of product could lead to surface whitening.
- Extreme climate or heavy traffic could limit product longevity.
- Frequent and aggressive maintenance will affect aggregate joint binding.

COVERAGE

As a concrete & wet-cast paver sealer and natural stone sealer: Single-coat application 1 gallon covers up to 150 sq. ft. / 5 gallons cover up to 750 sq. ft.

As a joint stabilizer: 1 gallon covers from 50 to 125 sq. ft. / 5 gallons cover from 250 to 625 sq. ft.

Coverage will depend on joint width and type as well as surface porosity.

STORAGE

Store in a cool, dry place.

CLEANING & DISPOSAL

Wash tools with lacquer thinner. Consult your retailer or municipality regarding the disposal of empty containers or unused product.

SAFETY WARNINGS

For information and advice regarding transportation, handling, storage, first aid and disposal of chemicals products, users should refer to the actual **Safety Data Sheet** containing physical, ecological, toxicological and other safety-related data.

KEEP OUT OF THE REACH OF CHILDREN

EMERGENCY PHONE: CANUTEC (613) 996-6666

Do not get in eyes. Do not get on skin or clothing.

FIRST AID TREATMENT If swallowed, call a Poison Control Centre or doctor immediately. Do not induce vomiting. If in eyes, rinse with water for 15 minutes. If on skin, rinse well with water.

SHIPPING

Land and sea

UN1993

Flammable liquid, n.o.s. (Acetone, ethylbenzene)

Class 3

PG : II

PACKAGING

Product	Product code	Size	Units per box	Units per pallet
Wet Look (WL5) Protector	60301532	1 gallon	4	180
	60301533	5 gallons	-	48
	60104320 Special Order	55 gallons	-	4

LIMITED WARRANTY

Having no control over the use of the products, Techniseal® does not guarantee finished work. Replacement of any defective product shall be the buyer's sole remedy under this warranty. A proof of purchase will be required for any claim. Before using this product, user shall determine the suitability of the product for its intended use, and user alone assumes all risks and liability whatsoever in connection therewith. User shall test product in a small inconspicuous area (approx. 4 sq. ft.) under projected conditions of use. In the event that no test was carried out, the warranty will only apply to 4 sq. ft. This limited warranty excludes any liability for any consequential, incidental, indirect or special damages. Except for the limited warranty described above, manufacturer specifically disclaims and excludes any other express warranty, any implied warranty of merchantability of goods, and implied warranty of fitness of goods for any particular purpose.